Allow sql server connection on Windows server (focicom) (1/2/24)

Problem:

The dev team wants to connect to sql server (database) but can't.

Cause:

Presence of a firewall not allowing connection to the database.


Problem solved:




https://www.apesoftware.com/calibration-control/help/sql-remote-connections

Steps

- Open SQL Server Management Studio
 - right-click on the server name (this is the first line of the list displayed by SQL Server Management Studio)



 In the "Connections" tab, check the box "Allow remote connection to this server".



• Open SQL Server Configuration Manager


- select the "SQL server network configuration" option
- Protocol for [server_name:in our case EBP]:


NB: SQL SERVER: software for storing data from databases registered in it

SQL server can have several instances, these instances can have their own rules: as on the picture below, the image has different protocols for each instance (Protocols for ...,)

These instances can be named (depending on the databases registered in them): in our case, it's named EBP (because it's the EBP database), but it can also be named EBP2019 (depending on the EBP version).


- right-click on TCP/IP, then "enable
- right-click on TCP/IP, then "property
 - search for "IPAII
 - enter port 1433 in the "TCP port field" box







• In SQL Server Services dialog, right-click on the server name, then restart (in our case, "SQL server EBP").


The services to be restarted are those of the instance concerned. For example, in the photo: if the instance is named MSSQLSERVER (Protocols for MSSQLSERVER), the service to be restarted is: SQL server MSSQLSERVER (if the service is not listed in the tab, restart it via the "services" tool).



- TCP (sql) is configured on port 1433, now we need to authorize it
 - o open windows firewall
 - o add a new rule
 - select the port option
 - o enter port 1433







- Add SQL Server application to authorize as well
 - click on new rule in windows firewall
 - select custom
 - select the customize button
 - select the "apply to this service" option
 - search for "SQL server EBP (in our case)" service

